

TR-iBASS7 BT STEREO SOUND DOUBLE SPEAKER


User manual

Please read this user manual carefully before use.

三：电性参数

蓝牙版本	V4.2
蓝牙距离	无障碍约 10 米距离
电池容量	1500 mAh
最大输出功率	3 W *2
喇叭功率	4Ω 3W 1.5 英寸
频响范围	100HZ-20KHZ
灵敏度	83 db, ± 2 db.
支持的音频格式	MP3 WAV
支持的内存容量	TF/ Micro SD up to 32 GB
电源供应	USB 5V /1000 mA
产品尺寸 (L*W*H)	L 6.6 *W 6.6 *H 18 CM
产品净重	405g

五：按键功能说明



按键	TF卡/蓝牙模式		BT 模式		通话模式		TF卡模式	
	长按	短按	长按	短按	长按	短按	长按	短按
电源/关机	无	无	无	无	无	无	无	无
模式切换	无	模式切换	模式切换	模式切换	无	接听/接听与音乐/接听/挂断电话	无	模式切换
播放/暂停	无	播放/暂停	播放/暂停	播放/暂停	接听/挂断电话	接听/挂断电话	无	播放/取消静音
音量+	无	音量+	音量+	音量+	无	无	无	音量+
音量-	无	音量-	音量-	音量-	无	无	无	音量-

同时按下“开/关机”键与“播放/暂停”键，系统断电复位

TF 卡模式：

当插入 TF 卡时，系统检测到 TF 插入时（有声音提示），会自动识别 TF 卡内的 MP3、WAV 格式音乐并自动播放（最大支持 32GB TF 卡）

AUX 音频输入
音响通过自带的 3.5mm 的音频接口和手机/平板/笔记本/电脑等设备来播放音乐，NFC 快速连接和音乐播放

打开手机里的 NFC 设置，用手机带 NFC 模块的部分接触音响后，便会自动连接成功，然后手机播放音乐即可。

充电：
将随机配送的数据线 Micro USB 端插入音箱的 USB 充电口，另一端连接能提供直流电压不超过 5V，电流不低于 1000mA 的充电设备上，音箱会自动进入充电模式，此时红色指示灯点亮，充电完成后，红色指示灯将熄灭。

温馨提示：当电池电量低时，音箱会每隔 25 秒有语音提醒您，电池电量低，请尽快充电！

自动延时关机：
在蓝牙模式无连接、TF 卡音乐暂停状态，按键无任何操作情况下，音箱 10 分钟后会自动进入省电状态自动关机。

七：常见问题分析及故障排除

- 开机后就自动关机：电量不足请充电后使用
- 播放自动关机或重启：电池电量不足导致电压过低无法播放，请充电后使用
- 喇叭没有声音：检查音量是否打开，也可以重启音箱试试
- 蓝牙无法连接：
 - 请检查音箱是否进入蓝牙模式；
 - 音箱有无与其它设备连接上,如有连接上，可以通过长按音箱上的“M”键强行与已连接的设备断开，并进入待配对模式；
 - 最后确认手机、平板电脑等蓝牙设备是否启用蓝牙功能，是否点击设备搜索
- 按键无功能或功能出错：请关机后再开机

一：重要安全信息

在使用手提蓝牙音箱之前，您需要确保遵守以下基本的安全提示，以保证产品的安全可靠的使用：

- 请仔细阅读本用户手册，遵守所有标注在产品上的警示和指引信息。
- 请勿将本产品遭受雨淋、受潮、滴上或溅上任何液体。
- 请勿将本产品靠近高温的热源，不可高温烘烤或吹干。
- 请勿让本产品跌落或受到撞击，或在上部施加重压
- 请勿长期使用最大音量播放音乐，可能会影响产品的使用寿命。
- 请使用输出直流电压不超过 5V，电流不低于 1000mA 的充电设备，以免造成产品损坏。
- 请勿擅自拆卸产品，以免得不到质量保证。
- 打雷闪电时请拔掉充电线或停止产品使用。
- 拔掉充电线时，请抓住充电头,而不是拽线本身。
- 避免直接暴露于极端高温或阳光直射的地方,以免损害产品。

二：配件清单

- 音箱* 1
- USB 数据线* 1
- AUX 音频线* 1
- 登山扣 *1
- 说明书* 1

TR-iBASS7 BT STEREO SOUND DOUBLE SPEAKER

Product data :

Bluetooth version	V4.2
Bluetooth transmission	up to 10m range
Battery capacity	1500 mAh
Max output	3 W *2
Horn spec	4Ω 3W 1.5 inch
Frequency response	100HZ-20KHZ
sensitivity	83 db, ± 2 db.
Supported audio formats	MP3 WAV
Max supported memory cards	TF/ Micro SD up to 32 GB
Power supply	USB 5V /1000 mA
Products size (L*W*H)	L 6.6 *W 6.6 *H 18 CM
weight	405g

六：快速使用

开/关机与蓝牙模式

- 长按电源按钮 3s 可进行开/关机操作，会有声音提醒；开机后蓝色指示灯点亮，无/AUX 音频连接/无 TF 卡插入情况下，音箱会自动进入蓝牙模式，并进入待配对状态；（如之前有配对成功的设备，音箱会自动与其连接成功）
- 打开手机、平板电脑等设备的蓝牙功能，点击搜索，当配对名“TR-iBASS7”出现在列表时，选择此配对名并连接，音箱会自动与设备配对并连接成功（有声音提示）
- 连接成功后，就可以在手机和平板电脑等蓝牙设备上播放音乐了。

四：产品基本功能

- 蓝牙连接，无线束缚
蓝牙 4.2 方案，更省电，抛开全线的有线连接，享受无线的音乐乐趣
- 超强低音，铿锵有力
内置低音增强硬件，使得音乐的低音更加铿锵有力
- 免提通话
自带免提通话功能，放开双手，无线享受
- 自带 TF 卡解码和音乐播放
完美的 MP3/WAV 通用格式解码可以轻松快速的读取 TF 卡内的音乐文件
- AUX 音频输入
音响通过自带的 3.5mm 的音频接口和手机/平板/笔记本/电脑等设备来播放音乐。
- NFC 快速连接和音乐播放
打开手机里的 NFC 设置，用手机带 NFC 模块的部分接触音响后，便会自动连接成功，然后手机播放音乐即可。
- 内置大容量高性能锂电池，超长续航
内置大容量锂电池，满足用户随时随地的音乐享受与需要。
- 充电指示，状态直观
充电时红灯常亮，充满后红灯熄灭
- 清晰明了的工作状态指示
蓝灯-完美指示各模式的工作状态，蓝灯快速闪烁指示：TF 卡播放、蓝牙播放、AUX 播放，蓝灯慢速闪烁指示：TF 卡暂停、蓝牙暂停、AUX 静音，蓝灯常亮指示：

二：配件清单

- 音箱* 1
- USB 数据线* 1
- AUX 音频线* 1
- 登山扣 *1
- 说明书* 1

Contents

Section 1: Introduction

- Important Notes
- List of accessories
- Product Features
- Buttons and controls

Section 1: Important Notes

- Please read this user manual carefully and save it for future reference.
- Don't expose the Speaker to moisture or excessive humidity.
- Do not drop or allow the speaker to be immersed in water.
- Long-term exposure to loud music may damage the speaker and therefore influence further performance. It will be better to avoid extreme volume when using the speaker.
- Please follow the warnings contained in these instructions.
- The only way to clean the Speaker is with a dry cloth or towel.
- Disassembling the Speaker without authorization will void your warranty.
- Please unplug the charging cord when lightning or not in use.
- When removing cords, grasp the plug and pull straight out, instead of tugging on the wire itself.
- Avoid exposing the Speaker directly to extreme heat or direct sunlight, which can damage the battery.

Contents

- 1* Bluetooth speaker
- 1* Usb Cable
- 1* Aux Cable
- 1* User Manual
- 1* Carabiner hook

Buttons and controls



- Play/pause/answer/hang up: short press the play pause key / answer/hang up, long press reject a call/dial
- Mode conversion: In the Bluetooth mode, press to enter the TF & AUX model
- Volume Plus: short press for the next song, long press for volume up
- Volume less: short press for the last song, long press for volume down
- Power button :Press and hold power button for 3s to power on/off.

Note : it will automatically turn off if not connected to any device in Bluetooth mode.

Bluetooth Function:

- Power button: Long press power button for 3s to turn on the speaker, there will be a voice prompt remind you that the Bluetooth speaker is ready for pairing, then the blue indicator light start to flash.
- Activate the Bluetooth function on your Bluetooth-enabled devices, search for "TR-iBASS7", and select it when it appears on the pairing list.
- There will a voice prompt saying "Paired" indicating the pairing is successful, then the blue LED indicator light will light on. In this situation, you can play the music files on your phone and tablet now.

NFC Function :

- Activate the NFC feature on your phone by turning it on in the "Wireless & Networks" section of the Settings menu.
- Touch the phone to the speaker
- A "Bluetooth Pairing Request" will appear on your phone. Select the "Pair" option that is included in the menu
- Your device is paired and whatever music you play on the phone will be heard over the speaker. Also the buttons on your speaker will now control the music on your phone

Hands Free Function:

Speaker and phone connection, the call sounded ringtones immediately as soon as wireless music pause, just short press key to answer and short press again to hang up the call. For reject the call, long press the call button

Aux in mode
Connect by 3.5 mm audio cable which end of the signal Input line to the player and other end to insert the speaker LINE input

TF card mode Function:
Insert TF card and turn on , the speaker will enter into TF Card mode automatically , or in the condition of bluetooth music play and TF card inserted , short press the M key switch to TF Card mode and play the music which in the TF Card .

Charging :
Use Micro USB cable inserted into the USB charging port of the speaker. The other end is connected to a charging device that can provide a DC voltage 5V and a current 1000mA. The speaker will automatically enter the charging mode. when red indicator light on means charging finish, then the red indicator light will be off.
(Warm tip: when the battery power is low, the speaker will have a voice reminder every 25 seconds, The battery power is low, please charge as soon as possible!)

Frequently Asked Questions (FAQ)/Troubleshooting

- Turn off automatically after power on: please use after charging when the power is low
- Play automatic shutdown or restart: the voltage is too low due to low battery power. Please use it after charging
The speaker is silent: check to see if the volume is turned on, or restart the speaker
- Bluetooth cannot connect:
A. Please check whether the speaker enters Bluetooth mode;
B. If the speaker is connected to other devices, it can be forced to disconnect the connected device by double-clicking the "M" key on the speaker and enter the mode to be matched;
C. Finally confirm whether Bluetooth function is enabled for mobile phones, tablets and other Bluetooth devices, and click the device to search
- No function button or function error: please turn it off before starting it

If the above problems cannot be solved, please reset the system (press power button and paly button at the same time).